



1. Picture of the window before.



2. Lay a sheet of plastic down and place one row of sandbags around window leaving at least six inches (6") on each side and one foot (1') in front. Overlap bags slightly.



3. Place a second row of sandbags next to the first row using the same method.



4. Place a third row of sandbags on top of the first two (2) rows, overlapping two (2) base rows and each sandbag as you go.



5. Pull plastic up and over sandbag wall, placing a few bags on top to hold plastic in place.